

PRC04 Connector Included Cable

More cables of different lengths are available through the website!!

Connector Included Cable

PRC04P Connector Support Model Number Table

Shape Specification	Number of Cores	CN1	Component Page	CN2	Component Page
P PT	8	PRC04-12A16-8AM12.5	302		
	12	PRC04-12A20S-12M14.5	302		
	14	PRC04-12A16-14M12.5	302		
	19	PRC04-12A20S-19M14.5	302		
	21	PRC04-12A26S-21M18	302		
	37	PRC04-12A26S-37M18	302		
S ST	8	PRC04-12A16-8AF12.5	302		
	12	PRC04-12A20S-12F14.5	302		
	14	PRC04-12A16-14F12.5	302		
	19	PRC04-12A20S-19F14.5	302		
	21	PRC04-12A26S-21F18	302		
	37	PRC04-12A26S-37F18	302		
PP	8	PRC04-12A16-8AM12.5	302	PRC04-12A16-8AM12.5	302
	12	PRC04-12A20S-12M14.5	302	PRC04-12A20S-12M14.5	302
	14	PRC04-12A16-14M12.5	302	PRC04-12A16-14M12.5	302
	19	PRC04-12A20S-19M14.5	302	PRC04-12A20S-19M14.5	302
	21	PRC04-12A26S-21M18	302	PRC04-12A26S-21M18	302
	37	PRC04-12A26S-37M18	302	PRC04-12A26S-37M18	302
SS	8	PRC04-12A16-8AF12.5	302	PRC04-12A16-8AF12.5	302
	12	PRC04-12A20S-12F14.5	302	PRC04-12A20S-12F14.5	302
	14	PRC04-12A16-14F12.5	302	PRC04-12A16-14F12.5	302
	19	PRC04-12A20S-19F14.5	302	PRC04-12A20S-19F14.5	302
	21	PRC04-12A26S-21F18	302	PRC04-12A26S-21F18	302
	37	PRC04-12A26S-37F18	302	PRC04-12A26S-37F18	302
PS	8	PRC04-12A16-8AM12.5	302	PRC04-12A16-8AF12.5	302
	12	PRC04-12A20S-12M14.5	302	PRC04-12A20S-12F14.5	302
	14	PRC04-12A16-14M12.5	302	PRC04-12A16-14F12.5	302
	19	PRC04-12A20S-19M14.5	302	PRC04-12A20S-19F14.5	302
	21	PRC04-12A26S-21M18	302	PRC04-12A26S-21F18	302
	37	PRC04-12A26S-37M18	302	PRC04-12A26S-37F18	302
PY	8	PRC04-12A16-8AM12.5	302	F1.25-3.5	468
	12	PRC04-12A20S-12M14.5	302	F1.25-3.5	468
	14	PRC04-12A16-14M12.5	302	F1.25-3.5	468
	19	PRC04-12A20S-19M14.5	302	F1.25-3.5	468
	21	PRC04-12A26S-21M18	302	F1.25-3.5	468
	37	PRC04-12A26S-37M18	302	F1.25-3.5	468
SY	8	PRC04-12A16-8AF12.5	302	F1.25-3.5	468
	12	PRC04-12A20S-12F14.5	302	F1.25-3.5	468
	14	PRC04-12A16-14F12.5	302	F1.25-3.5	468
	19	PRC04-12A20S-19F14.5	302	F1.25-3.5	468
	21	PRC04-12A26S-21F18	302	F1.25-3.5	468
	37	PRC04-12A26S-37F18	302	F1.25-3.5	468
RP RPT RPRT	8	PRC04-21A16-8AM	303		
	12	PRC04-21A20S-12M	303		
	14	PRC04-21A16-14M	303		
	19	PRC04-21A20S-19M	303		
	21	PRC04-21A26S-21M	303		
	37	PRC04-21A26S-37M	303		
RS RST RSRT	8	PRC04-21A16-8AF	303		
	12	PRC04-21A20S-12F	303		
	14	PRC04-21A16-14F	303		
	19	PRC04-21A20S-19F	303		
	21	PRC04-21A26S-21F	303		
	37	PRC04-21A26S-37F	303		

PRC04J Connector Support Model Number Table

Shape Specification	Number of Cores	CN1	Component Page	CN2	Component Page
JP JPT	8	PRC04-32A16-8AM12.5	302		
	12	PRC04-32A20S-12M14.5	302		
	14	PRC04-32A16-14M12.5	302		
	19	PRC04-32A20S-19M14.5	302		
	21	PRC04-32A26S-21M18	302		
	37	PRC04-32A26S-37M18	302		
JS JST	8	PRC04-32A16-8AF12.5	302		
	12	PRC04-32A20S-12F14.5	302		
	14	PRC04-32A16-14F12.5	302		
	19	PRC04-32A20S-19F14.5	302		
	21	PRC04-32A26S-21F18	302		
	37	PRC04-32A26S-37F18	302		
JPP	8	PRC04-32A16-8AM12.5	302	PRC04-12A16-8AM12.5	302
	12	PRC04-32A20S-12M14.5	302	PRC04-12A20S-12M14.5	302
	14	PRC04-32A16-14M12.5	302	PRC04-12A16-14M12.5	302
	19	PRC04-32A20S-19M14.5	302	PRC04-12A20S-19M14.5	302
	21	PRC04-32A26S-21M18	302	PRC04-12A26S-21M18	302
	37	PRC04-32A26S-37M18	302	PRC04-12A26S-37M18	302
JPS	8	PRC04-32A16-8AM12.5	302	PRC04-12A16-8AF12.5	302
	12	PRC04-32A20S-12M14.5	302	PRC04-12A20S-12F14.5	302
	14	PRC04-32A16-14M12.5	302	PRC04-12A16-14F12.5	302
	19	PRC04-32A20S-19M14.5	302	PRC04-12A20S-19F14.5	302
	21	PRC04-32A26S-21M18	302	PRC04-12A26S-21F18	302
	37	PRC04-32A26S-37M18	302	PRC04-12A26S-37F18	302
JSP	8	PRC04-32A16-8AF12.5	302	PRC04-12A16-8AM12.5	302
	12	PRC04-32A20S-12F14.5	302	PRC04-12A20S-12M14.5	302
	14	PRC04-32A16-14F12.5	302	PRC04-12A16-14M12.5	302
	19	PRC04-32A20S-19F14.5	302	PRC04-12A20S-19M14.5	302
	21	PRC04-32A26S-21F18	302	PRC04-12A26S-21M18	302
	37	PRC04-32A26S-37F18	302	PRC04-12A26S-37M18	302
JSS	8	PRC04-32A16-8AF12.5	302	PRC04-12A16-8AF12.5	302
	12	PRC04-32A20S-12F14.5	302	PRC04-12A20S-12F14.5	302
	14	PRC04-32A16-14F12.5	302	PRC04-12A16-14F12.5	302
	19	PRC04-32A20S-19F14.5	302	PRC04-12A20S-19F14.5	302
	21	PRC04-32A26S-21F18	302	PRC04-12A26S-21F18	302
	37	PRC04-32A26S-37F18	302	PRC04-12A26S-37F18	302
JPY	8	PRC04-32A16-8AM12.5	302	F1.25-3.5	468
	12	PRC04-32A20S-12M14.5	302	F1.25-3.5	468
	14	PRC04-32A16-14M12.5	302	F1.25-3.5	468
	19	PRC04-32A20S-19M14.5	302	F1.25-3.5	468
	21	PRC04-32A26S-21M18	302	F1.25-3.5	468
	37	PRC04-32A26S-37M18	302	F1.25-3.5	468
JSY	8	PRC04-32A16-8AF12.5	302	F1.25-3.5	468
	12	PRC04-32A20S-12F14.5	302	F1.25-3.5	468
	14	PRC04-32A16-14F12.5	302	F1.25-3.5	468
	19	PRC04-32A20S-19F14.5	302	F1.25-3.5	468
	21	PRC04-32A26S-21F18	302	F1.25-3.5	468
	37	PRC04-32A26S-37F18	302	F1.25-3.5	468
JPSP	8	PRC04-32A16-8AM12.5	302	PRC04-32A16-8AM12.5	302
	12	PRC04-32A20S-12M14.5	302	PRC04-32A20S-12M14.5	302
	14	PRC04-32A16-14M12.5	302	PRC04-32A16-14M12.5	302
	19	PRC04-32A20S-19M14.5	302	PRC04-32A20S-19M14.5	302
	21	PRC04-32A26S-21M18	302	PRC04-32A26S-21M18	302
	37	PRC04-32A26S-37M18	302	PRC04-32A26S-37M18	302
JSJS	8	PRC04-32A16-8AF12.5	302	PRC04-32A16-8AF12.5	302
	12	PRC04-32A20S-12F14.5	302	PRC04-32A20S-12F14.5	302
	14	PRC04-32A16-14F12.5	302	PRC04-32A16-14F12.5	302
	19	PRC04-32A20S-19F14.5	302	PRC04-32A20S-19F14.5	302
	21	PRC04-32A26S-21F18	302	PRC04-32A26S-21F18	302
	37	PRC04-32A26S-37F18	302	PRC04-32A26S-37F18	302
JPJS	8	PRC04-32A16-8AM12.5	302	PRC04-32A16-8AF12.5	302
	12	PRC04-32A20S-12M14.5	302	PRC04-32A20S-12F14.5	302
	14	PRC04-32A16-14M12.5	302	PRC04-32A16-14F12.5	302
	19	PRC04-32A20S-19M14.5	302	PRC04-32A20S-19F14.5	302
	21	PRC04-32A26S-21M18	302	PRC04-32A26S-21F18	302
	37	PRC04-32A26S-37M18	302	PRC04-32A26S-37F18	302

- MS Connector Included Cable
- MS Connector Included Cable (Drip-proof)
- JL04 Connector Included Cable
- JL05 Connector Included Cable
- NCS Connector Included Cable
- NJC Connector Included Cable
- NJW Connector Included Cable
- NR Connector Included Cable
- NRW Connector Included Cable
- NET Connector Included Cable
- PRC04 Connector Included Cable**
- PRC03 Connector Included Cable
- PRC05 Connector Included Cable
- R03 Connector Included Cable
- R04 Connector Included Cable
- PLT Connector Included Cable
- HR10 A Connector Included Cable
- XS2 Connector Included Cable
- DIN / Mini DIN Connector Included Cable