
[High Precision] Z-Axis Dovetail Slide, Feed Screw

Extended Knob / Reinforced Clamp




ZEGL

- Resolution (Vernier Scale Indication): 0.1mm/division
- Extension Cover HDEXT12 (Sold Separately): Ø12 feed screw knob can be extended. 🔊 P.2004
- 🕏 XY-Axis Mounting Plate XPLTE: Use this plate when connecting stages with non-matching mounting holes, 🝱 P.1915








- Extension Cover HDEXT12 (Sold Separately); Ø12 feed screw knob can be extended. 🖙 R2004






[Simplified Adjustments] Z-Axis, Feed Screw

For Set-Up Changes, For First Time Installment






◆Travel per Rotation: 1.5mm
◆Minimum Graduation: 0.5mm



The allowable loads are for using in Z-Axis configuration (in the orientation shown in the photo)



Part Number		Stage Surface	Travel Distance	Load Capacity	Weight	Unit Price
Type	No.	(mm)	(mm)	(N)	(g)	Unit Price
XKEMA	40	40x40	±3	49	70	
	60	60x60	±5	98	160	



The allowable loads are for using in Z-Axis configuration (in the orientation shown in the photo).